

How to:

Install Folding Commercial Sign Panels

Step #1

(2) 4" x 4" x 8' posts inserted approx. 24"-30" into the ground.

← Approx. 6 Feet →

Step #2

Plywood is attached to uprights using screws or nails.

48" x 80" or 48" x 96" Plywood



Step #3



Sign panel is unfolded.

Step #4



Sign panel is attached to plywood using drywall screws and small washers.

Step #5

(Optional)

For high wind areas or for signs which will be erected for a long time, re-enforce with additional support boards.



SOLD!



VIKING
SIGNS
and Graphic Design Studio

124 W. Grand River
P. O. Box 140
Webberville, MI 48892
800-270-1883
fax 517-521-4351